

vtech®

Instruction Manual

Ivy™
The Bloom
Bright Unicorn




91-003530-005 US

INTRODUCTION

Thank you for purchasing **Ivy the Bloom Bright Unicorn™!**

Tap the rainbow butterfly on the magic wand to choose a color. Touch her horn, eyes and wings with the wand to create a unique look. Play nine color and music games or tuck her legs in for cuddle time.



Comb and Jewelry Play Pieces



INCLUDED IN THIS PACKAGE

- Ivy the Bloom Bright Unicorn™
- 1 magic wand
- Quick Start Guide

WARNING

All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties, cords and packaging screws are not part of this toy, and should be discarded for your child's safety.

NOTE

Please save this Instruction Manual as it contains important information.

ATTENTION :

Pour la sécurité de votre enfant, débarrassez-vous de tous les produits d'emballage tels que rubans adhésifs, feuilles de plastique, attaches, étiquettes, cordons et vis d'emballage. Ils ne font pas partie du jouet.

NOTE :

Il est conseillé de sauvegarder ce manuel car il comporte des informations importantes.

GETTING STARTED

How to Exit Try-Me Mode

The Unicorn is in Try-Me mode in the packaging.

Slide the **Off/Low/High Volume Selector** at the bottom of the unicorn to turn the unit **Off** and then slide the switch to either **Low Volume** (◀) or **High Volume** (▶) to turn the unit **On** again.



WARNING:

CHOKING HAZARD - small parts
Not for children under 3 years.




ATTENTION :

DANGER D'ÉTOUFFEMENT - Petits éléments.
Ne convient pas aux enfants de moins de 3 ans.


Unlock the Packaging Locks

- ① Rotate the packaging locks 90 degrees counterclockwise.
- ② Pull out the packaging locks and discard.




Battery Installation (Unicorn)

1. Make sure the unit is turned Off.
2. Find the battery cover located on the underside of the unit, use a screwdriver to loosen the screw and then open the battery cover.
3. Remove old batteries by pulling up on one end of each battery.
4. Install 4 new AA batteries following the diagram inside the battery box.
5. Replace the battery cover and tighten the screw to secure.



Battery Installation (Magic Wand)

1. Make sure the unit is turned Off.
2. Find the battery cover located on the side of the unit, use a screwdriver to loosen the screw and then open the battery cover.
3. Remove old batteries by pulling up on one end of each battery.



4. Install 2 new AAA batteries following the diagram inside the battery box.
5. Replace the battery cover and tighten the screw to secure.



WARNING:

Adult assembly required for battery installation.
Keep batteries out of reach of children.



ATTENTION :

Les piles ou accumulateurs doivent être installés par un adulte.
Tenir les piles ou accumulateurs hors de portée des enfants.

IMPORTANT: BATTERY INFORMATION

- Insert batteries with the correct polarity (+ and -).
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Do not short-circuit the supply terminals.
- Remove batteries during long periods of non-use.
- Remove exhausted batteries from the toy.
- Dispose of batteries safely. Do not dispose of batteries in fire.

RECHARGEABLE BATTERIES:

- Remove rechargeable batteries from the toy before charging.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not charge non-rechargeable batteries.

PRODUCT FEATURES

1. Off/Low/High Volume Selector

To turn the unit **On**, slide the **Off/Low/High Volume Selector** to the **Low Volume** (◀) or **High Volume** (▶) position. To turn the unit **Off**, slide the **Off/Low/High Volume Selector** to the **Off** ● position.



2. Magic Wand

Touch the **Butterfly Sensor** on the **Magic Wand** to choose a color. Wave the **Magic Wand** close to Ivy to see her hair, horn, flower, eyes and wings glow in that color.

3. Horn, Eye And Wing Sensors

Touch the **Butterfly Sensor** on the **Magic Wand** to choose a color. Touch the tip of the **Magic Wand** to her **Horn Sensor** to apply the color to her horn, hair and flower. Touch the tip of the **Magic Wand** to her **Eye Sensor** to apply the color to her eyes. Touch the tip of the **Magic Wand** to her **Wing Sensor** to apply the color to her wings.



Horn Sensor



Eye Sensor



Wing Sensor

4. Nose Sensor

Boop Ivy's **Nose Sensor** to hear some sweet phrases and see her wings flap.



5. Sound Sensor

Play any sound and Ivy will interact with you, change colors and flap her wings. The louder you play the sound, the more color changes you will see.

6. Light-Up Charm Button

Press Ivy's **Light-Up Charm Button** to choose different games and see her light flash.



7. Flower and Wings

Ivy's flower blooms and wings flap when she talks and sings.

8. Automatic Shut-Off

To preserve battery life, **Ivy the Bloom Bright Unicorn™** will automatically power-down after several minutes without input. The unicorn can be turned on again by pressing **Light-Up Charm Button**. The **Magic Wand** can be turned on again by pressing the **Butterfly Sensor** to choose a color. If the unit powers down while playing, we suggest changing the batteries.

ACTIVITIES

Standing Mode

All Standing mode games can be selected by ensuring that Ivy is standing upright and then cycling through game modes by pressing her Light-Up Charm Button.

1. Magical Color Me Game

Let's learn how to apply some color on Ivy. Touch the **Butterfly Sensor** on **Magic Wand** to choose a color and use the tip of the wand to apply it on Ivy's horn, eyes or wings. Wave the magic wand near Ivy to see her lights glow and hear her adorable responses. Boop her nose to hear cute responses.

2. Sing with Me Game


Press Ivy's **Light-Up Charm Button** to hear her sing. When Ivy sings a song, her lights will flicker, her flower will bloom and she'll flap her wings. After the song is finished, choose a color on the **Magic Wand** and touch her horn, eyes and wings or wave the **Magic Wand** and she'll sing another song for you.

3. Blooming Flower

Blow a kiss towards Ivy to see her flower bloom and she will tell you how she loves you too!

4. Let's Roll Game

Play any of your favorite songs for Ivy and she will flicker her lights along to the music. Ivy listens best if you place the music player on her left side. The louder you play, the more her lights will flicker, but don't play too loud!



5. Fashion Color Game

Wanna know your fashion color? Light up the **Magic Wand** by touching the **Butterfly Sensor** and then wave it at Ivy. She'll light up and pick a magic fashion color for you!

6. Share With Me

Share something fun or sweet with Ivy to interact with her. Nothing to share? No worries, she's got something fun to share with you!

Cuddle Mode

All Cuddle mode games can be selected by tucking Ivy's legs forward until she is in Cuddle mode and then cycling through the game modes but pressing the **Light-Up Charm Button**.



7. Color Cuddle Game

Ivy needs your cuddles! Use the **Magic Wand** to touch Ivy or wave the wand to hear her as she tries to fall asleep. It really soothes Ivy when you gently boop her nose.

8. Color Dream Game

Everyone dreams! Ivy has her color dreamland too! Ivy has a magical color dreamland, too! Wave the **Magic Wand** to unlock the color of Ivy's dream! She'll tell you about her dream and loves to hear your dream color, too!

9. Sing Me a Lullaby Game

Ivy loves lullabies! Hug Ivy and sing her a soft lullaby to soothe her to sleep. Don't worry if you feel a little shy, Ivy's got a lullaby to sing for you!

SONG LYRICS

Flap Your Wings

We got the beat, we got the beat
We move our, move our, move our feet.
To the right, to the right
To the left and back
Jump, jump and spin
Now flap your wings! Flap your wings! Yeah, flap your wings again!
We got the beat, we got the beat,
We move our, move our, move our feet. Oh yeah!

Colors True

We've got our colors true
To share with me and you,
Lights shine!
Colors bright!
Gather 'round and spread delight!
Shine on, now.

Glow Bright

We're gonna glow bright, glow bright, with rainbow light!
We're gonna sparkle until the sky shines with light.
Glow bright, glow bright
All through the night,
We're gonna sparkle until we fill your life with delight.

We Got Every Color

We got every color, every single one,
We got all the colors, we got all the fun,
We got a rainbow, we got the light,
We got the glitter, watch us, glowin' bright.

Drop the Beat

Hooves go tappin' on clouds tonight
Wings go flappin' and fly alright
The horn gets its glow, gets its glow, gets its glow
Drop the beat, drop the beat
Hey, everybody drop the beat!

Live Your Dream

We're gonna flap our wings and light up the sky
We're gonna flap our wings and fly so high
We're gonna flap our wings and reach for the stars
You can live your dream no matter who you are
Let your colors shine!

Dream comes true

Let's spread color all across the sky
Let's make flowers bloom, you and I.
I've got a magical wish I hope comes true
My dream is to stay with you.

Sprinkle light

We could all use a little color, all use a little light.

Like a flower spreading its perfume

It makes everything feel all right,

Add a little color, sprinkle in some light,

Just might feel

A little appeal

And help make everything bright

CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat source.
3. Remove the batteries when the unit is not in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

TROUBLESHOOTING

If for some reason the unit stops working or malfunctions, please follow these steps:

1. Please turn the unit **Off**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit **On**. The unit should now be ready to play again.
5. If the product still does not work, replace an entire set of new batteries.

IMPORTANT NOTE:

If the problem persists, please call our **Consumer Services Department** at **1-800-521-2010** in the U.S., **1-877-352-8697** in Canada, or visit our website **vtechkids.com** and fill out our **Contact Us** form located under the **Customer Support** link. Creating and developing VTech products is accompanied by a responsibility that we take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to contact us with any problems and/or suggestions you might have. A service representative will be happy to help you.

Caution

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Supplier's Declaration of Conformity
47 CFR § 2.1077 Compliance Information

Trade Name: VTech®
Model: 5471
Product Name: Ivy the Bloom Bright Unicorn™
Responsible Party: VTech Electronics North America, L.L.C.
Address: 1156 W. Shure Drive, Suite 200,
Arlington Heights, IL 60004
Website: vtechkids.com

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE OPERATION.

**Visit our website for more
information about our products,
downloads, resources and more.**

vtechkids.com
vtechkids.ca

*Read our complete warranty policy online at
vtechkids.com/warranty
vtechkids.ca/warranty*



TM & © 2021 VTech Holdings Limited.
All rights reserved.
Printed in China.
91-003530-005 (US)