

**vtech**<sup>®</sup>

User's Manual

# Baby's Light-Up Laptop™



© 2013 VTech  
**Printed in China**  
91-002817-000 US<sup>CA</sup>

Dear Parent,

Ever notice the look on your baby's face when they learn something new through their own discovery? These self-accomplished moments are a parent's greatest reward. To help fulfill them, **VTech**<sup>®</sup> created the **Infant Learning**<sup>®</sup> series of toys.

These unique interactive learning toys directly respond to what children do naturally – play! Using innovative technology, these toys react to baby's interactions, making each play experience fun and unique as they learn age-appropriate concepts like first words, numbers, shapes, colors and music. More importantly, **VTech**<sup>®</sup>'s **Infant Learning**<sup>®</sup> toys develop baby's mental and physical abilities by inspiring, engaging and teaching.

At **VTech**<sup>®</sup>, we know that a child has the ability to do great things. That's why all of our electronic learning products are uniquely designed to develop a child's mind and allow them to learn to the best of their ability. We thank you for trusting **VTech**<sup>®</sup> with the important job of helping your child learn and grow!


Sincerely,

Your friends at **VTech**<sup>®</sup>

To learn more about the **Infant Learning**<sup>®</sup> series and other **VTech**<sup>®</sup> toys, visit [www.vtechkids.com](http://www.vtechkids.com)

# INTRODUCTION

Thank you for purchasing the **VTech® Baby's Light-Up Laptop™**! **Baby's Light-Up Laptop™** by VTech® encourages little ones to discover and learn about letters, numbers, shapes, animals and more. Six colourful shape buttons light up the screen to teach letters, numbers and more. The white and black piano keys create an entertaining musical response. Just like mom and dad's laptop, **Baby's Light-Up Laptop™** also comes with a cute little mouse that moves in eight directions for more learning fun!



# INCLUDED IN THIS PACKAGE

- One VTech® Baby's Light-Up Laptop™
- One user's manual

## WARNING:

All packing materials, such as tape, plastic sheets, packaging locks and tags are not part of this toy, and should be discarded for your child's safety.


## ATTENTION :

Pour la sécurité de votre enfant, débarrassez-vous de tous les produits d'emballage tels que rubans adhésifs, feuilles de plastique, attaches et étiquettes. Ils ne font pas partie du jouet.

## NOTE:

Please keep this instruction manual as it contains important information.

Unlock the packing locks:




- ① Rotate the packaging locks 90 degrees counter-clockwise.
- ② Pull out the packing locks.

# GETTING STARTED

## BATTERY INSTALLATION

1. Make sure the unit is turned **OFF**.
2. Locate the battery cover on the bottom of the unit. Use a coin or a screwdriver to loosen the screw.
3. Install 3 new 'AAA' (AM-4/LR03) batteries following the diagram inside the battery box. (The use of new alkaline batteries is recommended for maximum performance.)
4. Replace the battery cover and tighten the screw to secure.







## BATTERY NOTICE

- Use new alkaline batteries for maximum performance.
- Use only batteries of the same or equivalent type as recommended.
- Do not mix different types of batteries: alkaline, standard (carbon-zinc) or rechargeable (Ni-Cd, Ni-MH), or new and used batteries.
- Do not use damaged batteries.
- Insert batteries with the correct polarity.
- Do not short-circuit the battery terminals.
- Remove exhausted batteries from the toy.
- Remove batteries during long periods of non-use.
- Do not dispose of batteries in fire.
- Do not charge non-rechargeable batteries.
- Remove rechargeable batteries from the toy before charging (if removable).
- Rechargeable batteries are only to be charged under adult supervision.

# PRODUCT FEATURES

## 1. ON/OFF/VOLUME CONTROL SWITCH

To turn the unit **ON**, slide the **ON/OFF/VOLUME CONTROL SWITCH** to the **LOW VOLUME** (  ), or the **HIGH VOLUME** (  ) position. To turn the unit **OFF**, slide the **ON/OFF/VOLUME CONTROL SWITCH** to the **OFF** (  ) position.




## 2. AUTOMATIC SHUT-OFF


To preserve battery life, the **VTech® Baby's Light-Up Laptop™** will automatically power-down after approximately 35 seconds without input. The unit can be turned on again by pressing any button.

# ACTIVITIES


1. Slide the **on/off/volume control switch** to turn the unit on. You will hear a fun sing-along song and a phrase. The screen will display a variety of animations with the sound.




2. Select a mode by sliding the **mode selector switch** to the **Learning Mode**, **Spanish Mode** or **Discovery Mode**.




3. Press the **shape buttons** to learn the names of the shapes and hear short tunes and playful songs in the **Learning Mode**. In the **Spanish Mode** you will learn the names of the shapes and hear playful songs in English and Spanish. In the **Discovery Mode** you will hear sounds, learn colors and hear playful songs. The screen will display a variety of animations with the sound.




4. Press the **animal buttons** to learn colors, shapes, animal names and sounds and hear short tunes in the **Learning Mode**. In the **Spanish Mode** you will learn colors, shapes, animal names and sounds and hear short tunes in English and Spanish. In the **Discovery Mode** you will learn shapes, animal names and sounds and hear short tunes. The screen will flash a variety of animations with the sound.



5. Press the **piano keys** to hear sung music notes in the **Learning Mode**. In the **Spanish Mode** you will hear sung music notes in Spanish. In the **Discovery Mode** you will hear a variety of melodies. When a melody is playing, press the piano keys to hear the melody played note by note. Stop pressing the piano keys and the melody will start playing from the beginning. The screen will display a variety of animations with the sound.



6. Move the **mouse** to learn letters in the the **Learning Mode**. In the **Spanish Mode** you will learn numbers in English and Spanish. In the **Discovery Mode** you will learn numbers. The screen will display a variety of animations with the sound.



7. Open or close the laptop to hear fun sounds and encouraging phrases. The screen will display a variety of animations with the sound.



8. If there is no input to the unit after approximately 5 seconds, you will hear a fun song or encouraging phrases. If there is still no input after another 5 seconds, you will hear another phrase. If there continues to be no input after another 5 seconds, you will hear a short tune and the unit will automatically power-down.





## MELODY LIST

1. Alphabet Song
2. This Old Man
3. Twinkle, Twinkle Little Star
4. Row, Row, Row Your Boat
5. The Bear Went Over the Mountain
6. Hey Diddle Diddle
7. London Bridge
8. Peas Porridge Hot
9. Skip To My Lou
10. Three Blind Mice
11. Hickory Dickory Dock
12. Humpty Dumpty



## SONG LYRICS

### SONG 1

A, B, C, D, E, F, G.  
Red, blue, green,  
Learn colors with me!

### SONG 2

1-2-3-4-5,  
Circle, triangle, square.  
Numbers and shapes - learning is everywhere!

### SONG 3

Hola, it's time to say "Hello."  
Let's learn Spanish,  
"Vamos" - "Let's go!"

## SONG 4

A, B, C, D,  
E, F, G.  
H, I, J, K,  
L, M, N, O, P.  
Q, R, S,  
T, U, V.  
W, X,  
Y and Z.

## SONG 5

A, B, C, D, E, F, G [in English]  
A, B, C, D, E, F, G [in Spanish]  
H, I, J, K, L, M, N, O, P [in English]  
H, I, J, K, L, M, N, Ñ, O, P [in Spanish]  
Q, R, S, T, U, V [in English]  
Q, R, S, T, U, V [in Spanish]  
W, X, Y and Z [in English]  
W, X, Y y Z. [in Spanish]

## SONG 6

Red, orange, yellow, green, blue and purple!

## SONG 7

Red, orange, yellow, green, blue and purple!  
Rojo, naranja, amarillo, verde, azul y morado!

## SONG 8

1-2-3-4-5,  
6-7-8-9-10,  
Counting is fun.  
Let's count again from one.

## SONG 9

One, two, three, four, five,  
Uno-dos-tres-cuatro-cinco,  
Six, seven, eight, nine, ten,  
Seis-siete-ocho-nueve-diez,  
Counting is fun.  
Let's count again from one.

## CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat source.
3. Remove the batteries when the unit is not in use for an extended period of time.
4. Do not drop the unit on a hard surface and do not expose the unit to moisture or water.

# TROUBLESHOOTING

If for some reason the program/activity stops working or malfunctions, please follow these steps:

1. Turn the unit **OFF**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit **ON**. The unit should now be ready to play again.
5. If the product still does not work, replace with an entire set of new batteries.

If the problem persists, please call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada, and a service representative will be happy to help you.

For information on this product's warranty, please call **VTech**® at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada.

## **IMPORTANT NOTE:**

Creating and developing **Infant Learning** products is accompanied by a responsibility that we at **VTech**® take very seriously. We make every effort to ensure the accuracy of the information which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department at 1-800-521-2010 in the U.S., or 1-877-352-8697 in Canada with any problems and/or suggestions that you might have. A service representative will be happy to help you.

## NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates and uses radio frequency energy and if not installed and used in accordance with the manufacturer's instructions, may cause interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause interference with radio or television reception, which can be determined by turning the equipment on and off, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**Caution:** changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

CLASS 1  
LED PRODUCT