

vtech[®]
Baby

Parent's Guide

Sunny Days Activity Spiral™



INTRODUCTION

Thank you for purchasing the **Sunny Days Activity Spiral™!**


Twist it around a stroller or hang it from an infant carrier to keep young minds reaching with lively colors, patterns and textures that encourage learning with sweet songs, phrases and animal sounds.

Spiral Attachment

On/Off/Volume Selector

Attachment Tie

Light-Up Sun Button



INCLUDED IN THIS PACKAGE

- One **Sunny Days Activity Spiral™**
- One parent's guide

WARNING:

All packing materials such as tape, plastic sheets, packaging locks, removable tags, cable ties and packaging screws are not part of this toy, and should be discarded for your child's safety.

NOTE:

Please keep this parent's guide as it contains important information.

ATTENTION :

Pour la sécurité de votre enfant, débarrassez-vous de tous les produits d'emballage tels que rubans adhésifs, feuilles de plastique, attaches, étiquettes et vis d'emballage. Ils ne font pas partie du jouet.


NOTE :

Il est conseillé de conserver ce guide des parents car il comporte des informations importantes.

GETTING STARTED

Battery Removal and Installation

1. Make sure the unit is turned **Off**.
2. Locate the battery cover on the back of the light-up sun. Use a screwdriver to loosen the screws and open the battery cover.
3. Remove the old battery by pulling up on one side of the battery.
4. Install 1 new AAA (AM-4/LR03) battery following the diagram inside the battery box. (The use of a new alkaline battery is recommended for maximum performance.)
5. Replace the battery cover and tighten the screws to secure.



BATTERY NOTICE

- Use new alkaline batteries for maximum performance
- Use only batteries of the same or equivalent type as recommended
- Do not mix different types of batteries: alkaline, standard (carbon-zinc) or rechargeable, or new and used batteries
- Do not use damaged batteries
- Insert batteries with the correct polarity
- Do not short-circuit the battery terminals
- Remove exhausted batteries from the toy
- Remove batteries during long periods of non-use
- Do not dispose of batteries in fire
- Do not charge non-rechargeable batteries
- Remove rechargeable batteries from the toy before charging (if removable)
- Rechargeable batteries are only to be charged under adult supervision

MISE EN GARDE

- Utiliser des piles alcalines neuves pour des performances maximales
- Seules des piles du type recommandé doivent être utilisées
- Ne pas mélanger différents types de piles ou d'accumulateurs, ne pas mélanger des piles ou des accumulateurs neufs avec des usagés
- Ne pas utiliser des piles ou des accumulateurs endommagés
- Mettre en place les piles ou les accumulateurs en respectant les polarités + et -
- Ne pas mettre les bornes d'une pile ou d'un accumulateur en court-circuit (en reliant directement le + et le -)
- Enlever les piles ou les accumulateurs usagés du jouet
- Retirer les piles ou les accumulateurs en cas de non-utilisation prolongée
- Ne les jeter ni au feu ni dans la nature
- Ne pas tenter de recharger des piles non rechargeables
- Enlever les accumulateurs du jouet pour les recharger
- Les accumulateurs ne doivent être chargés que sous la surveillance d'un adulte


⚠ WARNING:

Do not let your baby play with the toy until it is properly attached to an infant carrier or stroller. Do not use in moving vehicles. Do not attach to cribs or play yards. Do not add additional strings or straps. Possible entanglement or strangulation risk if toy is used in ways other than those described in this parent's guide.

PRODUCT FEATURES

1. On/Off/Volume Selector

To turn the unit **On**, slide the **On/Off/Volume Selector** to the **Low** (🔊) or **High** (🔊🔊) volume position. You will hear a playful phrase and a song. To turn the unit **Off**, slide the **On/Off/Volume Selector** to the **Off** (●) position.



2. Attachment Ties

Use the **Attachment Ties** on both ends to secure the activity spiral to your stroller or infant carrier.



3. Automatic Shut Off

To preserve battery life, the **Sunny Days Activity Spiral™** will automatically power down after approximately 30 seconds without input. The unit can be turned on again by pressing the **Light-Up Sun Button** or pulling on the **Square Handle**.


Note:

If the unit repeatedly powers down while playing or the light-up button fades out, we suggest changing the batteries.

ACTIVITIES


1. Light-Up Sun Button

Press the **Light-Up Sun Button** to learn about colors, animals and hear playful songs, sounds and music. The light will flash with the sounds.



2. Square Handle

Pull the **Square Handle** to hear silly sounds, playful tunes and a song. The light will flash with the sounds.



MELODY LIST

1. A-Tisket, A-Tasket
2. Bingo
3. Boys and Girls Go Out to Play
4. Good Morning Merry Sunshine
5. Hey Diddle Diddle
6. Little Boy Blue
7. London Bridge
8. Old King Cole
9. Polly Wolly Doodle
10. Skip to My Lou

SING-ALONG SONG LYRICS

Song 1

I am shining, warm and bright,
My friends have come out to play.
Hello doggie woof, woof, woof.
Hello kitty meow, meow, meow.
Peek-a-boo my little friends,
I'm so glad you're here today!

Song 2

Did you ever see a puppy, a puppy, a puppy,
Did you ever see a puppy,
Who loves you so much?

Song 3

Hello baby, I see you!
Look in the mirror, peek-a-boo!

Song 4

Kitty, kitty playing in the sun,
She's so sweet and likes to have fun!

CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat sources.
3. Remove the battery if the unit will not be used for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

TROUBLESHOOTING

If for some reason the unit stops working or malfunctions, please follow these steps:

1. Turn the unit **Off**
2. Interrupt the power supply by removing the battery
3. Let the unit stand for a few minutes, then replace the battery
4. Turn the unit back **On**. The unit will now be ready to play again

IMPORTANT NOTE:

If the problem persists, please call our **Consumer Services Department** at **1-800-521-2010** in the U.S. or **1-877-352-8697** in Canada, or by going to our website at **vtechkids.com** and filling out our **Contact Us** form located under the **Customer Support** link. Creating and developing **VTech®** products is accompanied by a responsibility that we at **VTech®** take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to contact us with any problems and/or suggestions that you might have. A service representative will be happy to help you.

Caution:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Supplier's Declaration of Conformity

Trade Name: VTech®
Model: 5221
Product name: Sunny Days Activity Spiral™
Responsible Party: VTech Electronics North America, LLC
Address: 1156 W. Shure Drive, Suite 200,
Arlington Heights, IL 60004
Website: vtechkids.com

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES.
OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS:
(1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND
(2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED,
INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE
D OPERATION.

CAN ICES-3 (B)/NMB-3(B)

**CLASS 1
LED PRODUCT**

**Visit our website for more
information about our products,
downloads, resources and more.**

vtechkids.com



TM & © 2019 VTech Holdings Limited.
All rights reserved.

Printed in China.

91-003756-000 (US) (CN)