

vtech[®]
Baby

User's Manual

Dream & Play Light-up Mobile™



© 2009 VTech
Printed in China


91-002376-000-000 (美)

Dear Parent,

Ever notice the look on your baby's face when they learn something new through their own discovery? These self-accomplished moments are a parent's greatest reward. To help fulfill them, **VTech**[®] created the **Infant Learning**[®] series of toys.

These unique interactive learning toys directly respond to what children do naturally – play! Using innovative technology, these toys react to baby's interactions, making each play experience fun and unique as they learn age-appropriate concepts like first words, numbers, shapes, colors and music. More importantly, **VTech**[®]'s **Infant Learning**[®] toys develop baby's mental and physical abilities by inspiring, engaging and teaching.

At **VTech**[®], we know that a child has the ability to do great things. That's why all of our electronic learning products are uniquely designed to develop a child's mind and allow them to learn to the best of their ability. We thank you for trusting **VTech**[®] with the important job of helping your child learn and grow!

Sincerely,


Julia Fitzgerald
Vice President, Marketing
VTech Electronics, NA


To learn more about the **Infant Learning**[®] and other **VTech**[®] toys, visit www.vtechkids.com

INTRODUCTION

Thank you for purchasing the **VTech® Dream & Play Light-up Mobile™** learning toy!

The **VTech® Dream & Play Light-up Mobile™** plays 4 sing along songs, peaceful nature sounds and 40 soothing melodies. Five boldly colored dangling insects turn round and round with the music to help lull baby to sleep. Adjustable timer setting allows parents to customize the playing time to meet baby's needs.

TURNING MOBILE





INCLUDED IN THIS PACKAGE

- One VTech® Dream & Play Light-up Mobile™ activity panel
- One turning leaf
- One support post
- Five plush dangling characters
- One instruction manual
- Two crib attachment straps

WARNING: All packing materials, such as tape, plastic sheets, wire ties and tags are not part of this toy, and should be discarded for your child's safety.


GETTING STARTED

BATTERY INSTALLATION

1. Make sure the unit is turned **OFF**.
2. Locate the battery cover on the back of the unit. Use a coin or a screwdriver to loosen the screw.
3. Install 4 new 'AA' (AM-3/LR6) batteries following the diagram inside the battery box.
4. Replace the battery cover and tighten the screw to secure the battery cover.

BATTERY NOTICE

- Install batteries correctly observing the polarity (+, -) signs to avoid leakage.
- Do not mix old and new batteries.
- Do not mix batteries of different types: alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium).
- Remove the batteries from the



equipment when the unit will not be used for an extended period of time.

- Always remove exhausted batteries from the equipment.
- Do not dispose of batteries in fire.
- Do not attempt to recharge ordinary batteries.
- The supply terminals are not to be short-circuited.
- Only batteries of the same and equivalent type as recommended are to be used.

WE DO NOT RECOMMEND THE USE OF RECHARGEABLE BATTERIES.

DEMO TAG

The demo tag should be removed automatically when the product is taken out of the packaging. If the demo tag is still in position, please remove the plastic strip from the back of the product before placing in the crib. This will activate normal play.



With the **Dream & Play Light-up Mobile™**, safety comes first.

- Keep the mobile out of baby's reach. To avoid entanglement injuries, please remove the mobile portion from the crib once baby begins sitting or pushing up on all fours.
- Mobile age grade - Birth to 5 months
- The crib mobile is intended for visual stimulation and is not intended to be grasped by a child.
- If attached to the crib, remove when baby begins to push up on hands and knees.
- Always attach all provided fasteners (strings, straps, clamps, etc.) tightly to a crib or playpen according to the instructions. Check frequently. Attach only to cribs with sturdy rails and spindles. Do not attach to play pens with mesh walls.
- Do not add additional strings or straps to attach to a crib or playpen.

- To ensure your child's safety, the product should be assembled by an adult.
- Make sure the crib attachment straps are out of child's reach.
- When removing the **VTech® Dream & Play Light-up Mobile™** from the crib, please detach the crib attachment straps from the unit and keep the straps out of child's reach.


Assembly Instructions

1. Take the dangling insect and leaf piece and thread the cord up through the bottom of the hole in the large leaf. Set the knot so it rests on the smaller hole on the leaf.
2. Take the dangling insect piece and slide the cord through the slit in the leaf. Set the knot so it rests securely in the hole on the leaf.
3. Attach the turning leaf piece into the recessed slot on top of the mobile support post. You will hear a click when the post is inserted correctly.






- Slide the bottom of the mobile support post into the recessed slot on the top of the activity panel. You will hear a click when the post is inserted correctly.




- Place the unit in the crib against the top rail. Press the blue button and slide the crib attachment strap up through the slot behind the button. Repeat with the second crib attachment strap.




- Tie the cord securely around the nearest spindle. Pull slightly on the unit to make sure the straps have been securely fastened. The unit should be tight against the crib rail. Check the unit regularly to ensure it is secure.



- To detach the mobile from the activity panel, press the small blue button on the back of the activity panel and pull up on the mobile support post.



- To detach the crib attachment straps, open the battery door, then slide the switches next to the straps toward the center of the activity panel and pull the crib attachment straps free.



PRODUCT FEATURES

1. ON/OFF/TIME SELECTOR SWITCH

To turn the unit **ON**, slide the **ON/OFF/TIME SELECTOR SWITCH** to the 10, 15 or 20 minute time setting. To turn the unit **OFF**, slide the **ON/OFF/TIME SELECTOR SWITCH** to the **OFF**(●) position.



2. MODE SELECTOR SWITCH

Slide the **MODE SELECTOR SWITCH** to choose one of the three play modes.



3. MOBILE/LIGHT PLAY SWITCH

Slide the **MOBILE/LIGHT PLAY SWITCH** to select the desired setting. (🎵💡) plays lights and spins the mobile, (🎵) spins the mobile with no lights, (💡) plays lights only.



4. VOLUME CONTROL

Press the volume control buttons to choose the desired volume. Press the right button to increase the volume and press the left button to decrease the volume.



5. AUTOMATIC SHUT-OFF

To preserve battery life, the **VTech® Dream & Play Light-up Mobile™** will automatically power-down after the selected time has ended. The unit can be turned on again by pressing the music button or when the sound sensor detects baby's crying.

ACTIVITIES

1. Slide the **on/off/time selector switch** to the desired time setting. You will hear a welcoming response related to the selected mode.
2. Slide the **mode selector switch** to choose a mode of play. In the story mode, you will hear a variety of sung nursery rhymes followed by children's melodies. The soothing mode plays a variety of soft melodies and nature sounds. The melody mode plays a variety of soothing melodies.
3. Press the **music button** to change the melody, song or sound.



MELODY LIST


1. A-Tisket, A-Tasket
2. Humpty Dumpty
3. Jack and Jill
4. London Bridge
5. Three Little Kittens
6. Old King Cole
7. Row, Row, Row Your Boat

- 
- 
- 
8. Pop! Goes the Weasel
 9. Sing a Song of Sixpence
 10. Old MacDonald
 11. Bear Went Over the Mountain
 12. Farmer in the Dell
 13. Little Bo Peep
 14. Did You Ever See a Lassie?
 15. Oh Where Has My Little Dog Gone?
 16. Teddy Bears' Picnic
 17. Sur le pont d'Avignon
 18. Alouette
 19. Old Grey Mare
 20. Mary, Mary Quite Contrary
 21. Brahms' Lullaby
 22. Greensleeves
 23. Pachelbel's Canon in D
 24. New World Symphony
 25. Serenade
 26. Ode to Joy
 27. Sleeping Beauty Waltz Op. 66
 28. All Through the Night
 29. Au Clair de la Lune
 30. Moonlight Sonata
 31. Rock-a-bye Baby
 32. Air
 33. Fur Elise

- 
- 34. Sweet and Low
 - 35. Blue Danube Waltz
 - 36. Lavender's Blue
 - 37. Bicycle Built for Two
 - 38. The Swan
 - 39. Home Sweet Home
 - 40. Spring Song

SUNG SONG LYRICS

Song 1



Go to sleep my baby.
Sleep well, safe and sound.
Sweet dreams I wish for you.
Dear friends all around.
La la la la la.
La la la la la.
La la la la la.
La la la la la.

Song 2


Twinkle, twinkle, little star,
How I wonder what you are.

Song 3

Beautiful dreamer, wake unto me.
Starlight and dewdrops are awaiting thee.

Song 4

Rock-a-bye baby, in the tree top.
When the wind blows the cradle will rock.



CARE & MAINTENANCE

1. Keep the unit clean by wiping with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat source.
3. Remove the batteries when the unit is not in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.

TROUBLESHOOTING

If for some reason the program/activity stops working or malfunctions, please follow these steps:

1. Please turn the unit **OFF**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit **ON**. The unit should now be ready to play again.
5. If the product still does not work, replace with a new set of batteries.

If the problem persists, please call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada, and a service representative will be happy to help you.

For information on this product's warranty, please call **VTech**® 1-800-521-2010 in the U.S., or 1-877-352-8697 in Canada.


IMPORTANT NOTE:

Creating and developing **Infant Learning** products is accompanied by a responsibility that we at **VTech**[®] take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department at 1-800-521-2010 in the U.S., or 1-877-352-8697 in Canada, with any problems and/or suggestions that you might have. A service representative will be happy to help you.

FCC Notice:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help



THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRED OPERATION.

THIS CLASS B DIGITAL APPARATUS COMPLIES WITH CANADIAN ICES-003.

CET APPAREIL NUMÉRIQUE DE LA CLASSE B EST CONFORME À LA NORME NMB-003 DU CANADA.

Caution : Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

