

vtech[®]

User's Manual

Pull & Sing Kitten™



© 2015 VTech
Printed in China
91-001664-008 US CN

Dear Parent,

Ever notice the look on your baby's face when they learn something new through their own discovery? These self-accomplished moments are a parent's greatest reward. To help fulfill them, **VTech**® created the **Infant Learning**® series of toys.

These unique interactive learning toys directly respond to what children do naturally – play! Using innovative technology, these toys react to baby's interactions, making each play experience fun and unique as they learn age-appropriate concepts like first words, numbers, shapes, colors and music. More importantly, **VTech**®'s **Infant Learning**® toys develop baby's mental and physical abilities by inspiring, engaging and teaching.

At **VTech**®, we know that a child has the ability to do great things. That's why all of our electronic learning products are uniquely designed to develop a child's mind and allow them to learn to the best of their ability. We thank you for trusting **VTech**® with the important job of helping your child learn and grow!


Sincerely,

Your friends at **VTech**®

To learn more about **VTech**® toys, visit vtechkids.com

INTRODUCTION

Thank you for purchasing the **VTech® Pull & Sing Kitten™** learning toy!
The **Pull & Sing Kitten™** is a cheerful interactive kitten that loves to play with the big ball of yarn! Pull the kitten along or press the letter buttons and the kitten will introduce letters, colors and play music.




INCLUDED IN THIS PACKAGE

- One VTech® Pull & Sing Kitten™ learning toy
- One user's manual

WARNING: All packing materials, such as tape, plastic sheets, packaging locks and tags are not part of this toy, and should be discarded for your child's safety.

ATTENTION : Pour la sécurité de votre enfant, débarrassez-vous de tous les produits d'emballage tels que rubans adhésifs, feuilles de plastique, attaches et étiquettes. Ils ne font pas partie du jouet.




NOTE: Please keep this instruction manual as it contains important information.

GETTING STARTED

BATTERY INSTALLATION

1. Make sure the unit is turned **OFF**.
2. Locate the battery cover on the back of the kitten. Use a screwdriver to loosen the screw.
3. Install 2 new AAA (LR03/AM-4) batteries following the diagram inside the battery box. (The use of new



alkaline batteries is recommended for maximum performance.)

4. Replace the battery cover and tighten the screw to secure.


BATTERY NOTICE

- Use new alkaline batteries for maximum performance.
- Use only batteries of the same or equivalent type as recommended.
- Do not mix different types of batteries: alkaline, standard (carbon-zinc) or rechargeable (Ni-Cd, Ni-MH), or new and used batteries.
- Do not use damaged batteries.
- Insert batteries with the correct polarity.
- Do not short-circuit the battery terminals.
- Remove exhausted batteries from the toy.
- Remove batteries during long periods of non-use.
- Do not dispose of batteries in fire.
- Do not charge non-rechargeable batteries.
- Remove rechargeable batteries from the toy before charging (if removable).
- Rechargeable batteries are only to be charged under adult supervision.

PRODUCT FEATURES

1. ON/OFF/VOLUME CONTROL SWITCH


To turn the unit **ON**, slide the **ON/OFF/VOLUME CONTROL SWITCH** to the **LOW VOLUME** (🔊) or the **HIGH VOLUME** (🔊🔊) position. To turn the unit **OFF** (🔇), slide the **ON/OFF/VOLUME CONTROL SWITCH** to the **OFF** (🔇) position.





2. PULL CORD

To convert the unit from a push toy to a pull toy, remove the pull cord from the storage compartment on the back of the **Pull & Sing Kitten™**. For your child's safety we suggest you store the pull cord in the compartment until your child is walking and to supervise your child when playing with the pull cord.





3. AUTOMATIC SHUT OFF

To preserve battery life, the **VTech® Pull & Sing Kitten™** will automatically power-down after approximately 30 seconds without input. The unit can be turned on again by pressing any button or by rolling the wheels twice during 1 second.



ACTIVITIES

1. Slide the **on/off/volume control switch** to turn the unit on. You will hear a kitten sound, a phrase and a song. The light will flash with the sounds.
2. Pull the kitten to hear a variety of phrases, sounds and melodies. The light will flash with sounds.
3. Press the **letter buttons** to learn letters and colors and hear playful songs and melodies. The light will flash with sounds.



4. If there is no input after approximately 8 seconds, you will hear a fun phrase. After another 8 seconds without input, you will hear another fun phrase. If there continues to be no input for another 8 seconds, the unit will play a short tune and power down. The unit can be turned on again by pressing any button or by pulling the kitten.

SUNG SONG LYRICS

SONG 1

I'm a little kitty, I like to play,
Pull me and I will follow you!
Meow meow meow.

SONG 2

I have one little nose.
It twinkles when we play together.

SONG 3

A-B-C-D
E-F-G
H-I-J-K
L-M-N-O-P
Q-R-S
T-U-V
W-X
Y and Z
Now I know my ABC's,
Next time, won't you sing with me?

SONG 4

I have three colorful stripes 1-2-3.
Touch my stripes and we can play!

SONG 5

I have two perky little ears,
When I hear your happy voice,
It makes me purr.

MELODY LIST:

1. Hey Diddle Diddle
2. Camptown Races
3. The Entertainer
4. Ring Around the Rosy
5. Three Little Kittens
6. Yankee Doodle
7. Take Me Out to the Ball Game
8. Can Can
9. Clementine
10. Three Blind Mice
11. Hot Cross Buns
12. Bicycle Built for Two

CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat source.
3. Remove the batteries when the unit is not in use for an extended period of time.
4. Do not drop the unit on hard surfaces.

TROUBLESHOOTING

If for some reason the program/activity stops working or malfunctions, please follow these steps:

1. Please turn the unit **OFF**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit **ON**. The unit should now be ready to play again.
5. If the product still does not work, replace with a new set of batteries.

If the problem persists, please call our Consumer Services Department at 1-800-521-2010 in the U.S. or 1-877-352-8697 in Canada, and a service representative will be happy to help you.

IMPORTANT NOTE:

Creating and developing **Infant Learning** products is accompanied by a responsibility that we at **VTech**® take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to call our Consumer Services Department at 1-800-521-2010 in the U.S., or 1-877-352-8697 in Canada, with any problems and/or suggestions that you might have. A service representative will be happy to help you.

FCC Notice:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

Caution : Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.