

vtech[®]
baby

Instruction Manual

Snuggle & Discover Baby Whale™




INTRODUCTION

Thank you for purchasing the **Snuggle & Discover Baby Whale™**. Cuddle up with a wonderful whale with multiple textures, a light-up heart and five piano keys. Explore a sea of wonders!

Ocean Sounds Button

Heart Button



Music Button

Piano Keys

On/Off/Volume Selector

INCLUDED IN THE PACKAGE

- Snuggle & Discover Baby Whale™
- Quick Start Guide

WARNING

All packing materials, such as tape, plastic sheets, packaging locks, removable tags, cable ties, cords and packaging screws are not part of this toy, and should be discarded for your child's safety.

NOTE

Please save this Instruction Manual as it contains important information.

ATTENTION

Pour la sécurité de votre enfant, débarrassez-vous de tous les produits d'emballage tels que rubans adhésifs, feuilles de plastique, attaches, étiquettes et vis d'emballage. Ils ne font pas partie du jouet.

NOTE

Il est conseillé de sauvegarder ce manuel d'instructions car il comporte des informations importantes.


IMPORTANT NOTES

- Please remove the plastic film from the mirror and discard before use.
- This product is in try-me mode in the packaging. To activate normal play, turn the unit **Off**, then slide the **On/Off/Volume Selector** to the Low volume **⏮** or High volume **⏭** position.

GETTING STARTED

Battery Removal and Installation

1. Make sure the unit is turned **Off**.
2. Find the battery cover located on the bottom of the electronic module, use a screwdriver to loosen the screw, and then open the battery cover.
3. Remove old batteries by pulling up on one end of each battery.
4. Install 2 new AA (AM-3/LR6) batteries following the diagram inside the battery box. (For best performance, alkaline batteries or fully charged Ni-MH rechargeable batteries are recommended.)
5. Replace the battery cover and tighten the screw to secure.



WARNING:

Adult assembly required for battery installation.
Keep batteries out of reach of children.



ATTENTION :

Les piles ou accumulateurs doivent être installés par un adulte.
Tenir les piles ou accumulateurs hors de portée des enfants.

IMPORTANT: BATTERY INFORMATION

- Insert batteries with the correct polarity (+ and -).
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries.
- Only batteries of the same or equivalent type as recommended are to be used.
- Do not short-circuit the supply terminals.
- Remove batteries during long periods of non-use.
- Remove exhausted batteries from the toy.
- Dispose of batteries safely. Do not dispose of batteries in fire.


RECHARGEABLE BATTERIES

- Remove rechargeable batteries (if removable) from toy before charging.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not charge non-rechargeable batteries.

PRODUCT FEATURES

1. On/Off/Volume Selector

To turn the unit **On**, slide the **On/Off/Volume Selector** located on the electronic module to the Low volume **))** or High volume **)))** position. You will hear a sound, phrases, and a song. To turn the unit **Off**, slide the **On/Off/Volume Selector** to the **Off ●** position.



2. Automatic Shut-Off

To preserve battery life, the **Snuggle & Discover Baby Whale™** will automatically power down after approximately 25 seconds without input. The unit can be turned on again by pressing any button.


NOTE

If the unit powers down or the light fades out during play, please install a new set of batteries.

ACTIVITIES


1. Heart Button

Press the **Heart Button** to play fun whale facts and songs. The light will flash with the sounds.




2. Piano Keys

Press the **Piano Keys** to learn about animals, numbers, counting, colors and shapes, hear fun sounds and short tunes. The light will flash with the sounds.




3. Music Button

Press the **Music Button** to hear sing-along songs and melodies. When a melody is playing, press the **Piano Keys** to hear the song played note by note. The light will flash with the sounds.



4. Ocean Sounds Button

Press the **Ocean Sounds Button** to hear fun underwater sounds. The light will flash with the sounds.



MELODIES

1. MacNamara's Band
2. Row, Row, Row Your Boat
3. Aiken Drum
4. Blue Danube Waltz
5. Looby Loo
6. Blow the Man Down
7. Sailor's Hornpipe
8. Skip to My Lou
9. Glow Worm
10. Colonel Bogey March
11. Chopsticks
12. Dill Pickles Rag
13. Sailing, Sailing
14. Diddle, Diddle, Dumpling
15. Humpty, Dumpty

SONG LYRICS

Song 1

Big, big whale, swimming in the sea.
Big, big whale, singing merrily.
In the ocean with all of my friends,
Splishing and splashing again and again!

Song 2

Diving, diving, down in the deep blue sea.
Swimming here, swimming there,
So many fun things to see!

Song 3

I'm a splishy, splashy whale,
Would you like to come play with me?

Song 4

I'm a big whale, living in the sea.
When I come up for air, you'll see me spout!
Water sprays out of my blowhole like a fountain.
I like to make a splash with my tail,
Then I'll take a big breath and dive down to the bottom of the sea.

Song 5

Crab's two claws go snip, snip, snap!
Snip, snap, snippity snap!

Song 6

Fishy, fishy, swimming in the sea,
Puff, puff, puffer fish, puffs up like a ball!

Song 7

Jellyfish is in the sea, wiggling and jiggling for us to see.

Song 8

Sea turtle peaceful and calm,
Quietly glides through the water.

Song 9

Playful dolphin, whistles and clicks,
Splishes and splashes and dives in the sea.

CARE & MAINTENANCE

1. Keep the unit clean by wiping it with a slightly damp cloth.
2. Keep the unit out of direct sunlight and away from any direct heat sources.
3. Remove the batteries if the unit will not be in use for an extended period of time.
4. Do not drop the unit on hard surfaces and do not expose the unit to moisture or water.
5. The plush whale is surface washable only. Do not submerge the whale in water.

TROUBLESHOOTING

If for some reason the unit stops working or malfunctions, please follow these steps:

1. Turn the unit **Off**.
2. Interrupt the power supply by removing the batteries.
3. Let the unit stand for a few minutes, then replace the batteries.
4. Turn the unit **On**. The unit should now be ready to use again.
5. If the unit still does not work, install a new set of batteries.

IMPORTANT NOTE:

If the problem persists, please call our **Consumer Services Department** at **1-800-521-2010** in the U.S. or **1-877-352-8697** in Canada, or by going to our website at **vtechkids.com** and filling out our **Contact Us** form located under the **Customer Support** link. Creating and developing VTech products is accompanied by a responsibility that we take very seriously. We make every effort to ensure the accuracy of the information, which forms the value of our products. However, errors sometimes can occur. It is important for you to know that we stand behind our products and encourage you to contact us with any problems and/or suggestions that you might have. A service representative will be happy to help you.

NOTE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Supplier's Declaration of Conformity

47 CFR § 2.1077 Compliance Information

Trade Name:	VTech®
Model:	5628
Product Name:	Snuggle & Discover Baby Whale™
Responsible Party:	VTech Electronics North America, L.L.C.
Address:	1156 W. Shure Drive, Suite 200 Arlington Heights, IL 60004
Website:	vtechkids.com

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRED OPERATION.
CAN ICES-3 (B)/NMB-3(B)

**Visit our website for more
information about our products,
downloads, resources and more.**

vtechkids.com
vtechkids.ca

Read our complete warranty policy online at
vtechkids.com/warranty
vtechkids.ca/warranty

